

PolyCom SoundPoint 321 - Configuration

Find IP Address via Menu >> Status >> Network >> TCP/IP Parameters

Then in Browser navigate to that IP.

Username = Polycom

Password = 456

Then Head over to SIP and Configure